
000111110001

Cascade Impedance Standard SubstrateMap

> P/N: 103-726


Pitch: 100 µm - 250 µm

Configuration: SG





> Key to Map Key to the 103-726 Map



All of the above specifications are based on an overtravel (downward movement of probe after initial touchdown on the substrate) of 75-125 μ m. This amount of overtravel can be set before calibration on the Impedance Standard Substrate (ISS) using the alignment marks (allows precise setting of probe separation and overtravel). Figure 1 shows that initial contact with the edge of the probe tips should be made at reference plane X (midpoint between the outer flat edge and the internal apex). The desired overtravel and thus skate (forward movement of probe tips after initial contact with substrate) is then achieved by adjusting the Z height on the positioner to move the edge of the probe tips to reference plane Y (midpoint between the internal apex and the flag points). This can also be seen from the photographic images shown in Figure 2.




Figure 1: Alignment marks

Figure 2: Images showing correct alignment and placement of probe tips

Calibration Coefficients are dependent on the probe tip configuration, placement on a standard, and the standard configurations. This leads to unique calibration coefficients for a unique pair of probe and ISS. Therefore, the calibration coefficients are supplied with the probe not with the ISS.

© Copyright 2020 FormFactor, Inc. All rights reserved. FormFactor and the FormFactor logo are trademarks of FormFactor, Inc. All other trademarks are the property of their respective owners. All information is subject to change without notice.

Document PN: 104-199 rev C

Corporate Headquarters 7005 Southfront Road Livermore, CA 94551 Phone: 925-290-4000

FORMFACTOR