



This guide contains information to help prepare your facility for the arrival of your PLC50 probe system.

Probe System Requirements


Utilities	Compressed dry air	 Filtered, dry and oil-free Minimum 5 bar to 6 bar maximum Flow rate insignificant 8 mm OD hose (US: 5/16-inch) 	
	Nitrogen gas, (probe station)	Class 4.5 (Purity 99.995%) or better4 bar70 I per purging cycle8 mm OD hose	
	Nitrogen gas, (dewar) option, only required for LN2 dewar	 Class 4.5 (Purity 99.995%) or better 1.5 bar (precision pressure regulator suitable for low-flow condition is required) Flow rate insignificant 6 mm OD hose 	
	Helium gas (dewar) option, only required for LHe dewar	 Class 4.5 (Purity 99.995%) or better 1.2 bar (precision pressure regulator suitable for low-flow condition is required) Flow rate insignificant 6 mm OD hose 	
	Liquid gas (LHe or LN2)	One dewar with liquid gas (LHe or LN2, depending on probing temperature) is required to operate the PLC50. Contact a Cascade Microtech representative to verify ability for pressurizing the dewar and interface to transfer tube when using customer-owned or rented dewars.	
Power	Station	3-Phase 400 V 50/60 Hz, or3-Phase 208 V 50/60 Hz	
	Connection	 IEC 60309 16 A 3P+N+E (CEE plug 16 A), or NEMA L21-20P (20 A plug), or Direct connection without plug 	
	Facility power line	Cross section 5 x 4 mm ² 5x AWG#12)	
	Fuse	Lead in fuse 3 x 20 A (time delayed)	
	Protection class	• I (IEC 61140)	
	Transient overvoltage	Overvoltage category II (IEC 60364-4-443)	
Environmental	Humidity	• Tool area: 25% to 60%	
Conditions	Temperature	Operating range: 19° C to 24° C Target temperature: 22°C	
	Heat Output	1000W (typical value)	
	Pollution level	• 1 (IEC 60664-1)	
	Vibrations	The facility should be free of vibrations caused by other equipment.	
	WARNING Pales of nitre	agan as balium gas impasses a notantial danger due to avugan deplation in the working	
	Release of nitrogen or helium gas imposes a potential danger due to oxygen depletion in the working environment. An oxygen-deficient atmosphere can lead to rapid asphyxiation, causing loss of consciousness and potentially resulting in serious injury or death.		
	Consult your safety and facilities departments to ensure that the venting in your working environment is adequate to dissipate any nitrogen or helium build-up.		
	The use of an oxygen sensor with an alarm is recommended.		
Exhaust	Cryogenic system Vacuum system	 3/4-inch hose (connection point: rack) 3/4-inch hose (connection point: pump station)	

PLC50 Cryogenic Probe System

Dimensions	Probe station	 Station: 800 mm (W) x 810 mm (D) x 972 mm (H) 	
		Station with microscope: 1318 mm (H)	
	Pump station	• 392 mm (W) x 400 mm (D) x 492 mm (H)	
	Rack	• 580 mm (W) x 550 mm (D) x 1130 mm (H)	
	Dewar (typical data)	120 I LN2 storage dewar: 1250 mm x 550 mm (H x Ø)	
		 120 I LHe transport dewar: 1450 mm x 700 mm (H x Ø) 	
Weight	Probe station	• 230 kg	
	Pump station	• 36 kg	
	Rack	• 100 kg	
	Dewar (typical data)	120 I LN2 storage dewar: 70 kg (empty)/170 kg (filled)	
		 120 I LHe transport dewar: 145 kg (empty)/160 kg (filled) 	
Shipping	NOTE		
Dimensions and Weight	A forklift with	1 m (minimum) forks is required to move the station.	
	Probe station	• Dimensions: 1430 mm (W) x 1310 mm (D) x 1830 mm (H)	
		Weight: 400 kg	
	Accessories (typical	 Dimensions: 1300 mm (W) x 1300 mm (D) x 1800 mm (H) 	
	data)	Weight: 300 kg	


Dimensions (in mm)

Front view



PLC50 Cryogenic Probe System

Top view



© Copyright 2018 FormFactor, Inc. All rights reserved. No part of this document may be reproduced, transmitted or displayed in any form or by any means except as duly authorized by FormFactor, Inc. FormFactor and the FormFactor logo are trademarks of FormFactor, Inc. All other trademarks are the property of their respective owners.

Important Notice

While the information contained herein is believed to be accurate as of the date hereof, no express or implied representations or warranties are made with respect to its accuracy or completeness. FormFactor, Inc., and its subsidiaries disclaim liability for any inaccuracies or omissions. All information is subject to change without notice.

Users are required to read and follow carefully all safety, compliance and use instructions. Users assume all loss and liability arising from the use of products in any manner not expressly authorized. The conditions and methods of use of products and information referred to herein are the entire responsibility of the user and, to the maximum extent permitted by applicable law, FormFactor, Inc., and its subsidiaries shall not be liable for any damages, losses, costs or expenses arising out of, or related to, the use thereof.

No license, express or implied, by estoppel or otherwise, under any intellectual property right is granted in connection herewith. Users shall take all actions required to avoid intellectual property infringement.

Corporate Headquarters

7005 Southfront Road Livermore, CA 94551 Phone: 925-290-4000 www.formfactor.com

