

Pyramid Probes: Parametric PCB Cleaning

(Agilent 4070/4080 Series)



Quick Reference Guide

Follow the procedures described in this guide to protect your investment, prevent probing errors and avoid device damage. This guide provides a comprehensive overview of the required materials, as well as a detailed description of the process for cleaning the parametric printed circuit board (PCB). To ensure the best results, follow all the directions thoroughly.



CAUTION

- Always wear clean gloves when handling parametric boards.
- To prevent damage and/or contamination during the cleaning process, always set the PCB on a cleanroom cloth.
- Use only methanol, CMOS grade, when cleaning Pyramid parametric PCBs.



NOTE

The following operating environment is typical for parametric PCBs:

- Temperature: +19°C to +23°C (+67°F to +73°F)
- Relative humidity: 30% to 60%

Required Materials

The following materials are required for the PCB cleaning process:

- Printed circuit board for cleaning
- ITW Texwipe TechniCloth Wipers (TX612) (or similar grade wiper)
- ITW Texwipe Large Flexible Head Foam Swabs (TX710A) (or similar grade swab)
- Methanol, CMOS grade, in a squeeze bottle (not a reservoir)
- Clean, dry air (CDA) or nitrogen (N₂) nozzle
- Cleanroom gloves
- 100°C oven


Cleaning the PCB Tester Side

Remove the Core and PCB Cover

1. If necessary, remove the core from the PCB. See the *Pyramid Probe Core User Guide* for details on installing/uninstalling the core.
2. Carefully place the PCB on top of a cleanroom wipe on a flat surface.

Pyramid Probes: Parametric PCB Cleaning

3. Use a 1/16-inch hex wrench to remove the screws securing the PCB cover to the stiffener.



4. Remove the cover. Set the cover and screws aside.



NOTE

Removing the cover allows for better access to the cables and will not affect the board planarity.


Clean the Core Interface Area

1. Apply methanol from a squeeze bottle directly to a foam swab.
2. Use the foam swab to clean around the solder joint.
3. Stroke the swab smoothly along the trace towards the interface opening.
4. Repeat steps for each solder joint and trace, using a clean foam swab for each quadrant.
5. Blow CDA or N_2 across each quadrant, directing the air flow from the solder joint towards the interface opening.




NOTE

Always use CDA or N_2 to dry the PCB surface. If methanol is allowed to air dry on the PCB surface, re-wipe with a methanol-dampened swab.



Clean the solder joint and trace




Blow CDA or N_2 towards the interface opening

Pyramid Probes: Parametric PCB Cleaning


Clean the Outer Area of the Upper Board

Solder Joints

1. Apply methanol from a squeeze bottle directly to a foam swab.
2. Stroke the foam swab across one group of solder joints.
3. Blow CDA or N₂ from the solder joints towards the edge of the board.



Clean the solder joint



Blow CDA or N₂ towards the board edge


4. Repeat [step 2](#) and [step 3](#) in this section ([Solder Joints](#)) for each group of solder joints.

Spring Pin Area

1. Use a Texwipe dampened with methanol to wipe in a single direction around the entire spring pin area.
2. Blow CDA or N₂ from the solder joints towards the edge of the board.



Wipe spring pin area in a single direction




Blow CDA or N₂ towards the board edge

Pyramid Probes: Parametric PCB Cleaning

Cleaning the Wafer Side

Clean the Upper and Lower Board

1. Use a Texwipe dampened with methanol to wipe in one direction around the entire upper board.
2. Blow CDA or N_2 in the same direction that you wiped the board.




Wipe upper board in a single direction



Blow CDA or N_2 in the same direction

3. Repeat [step 1](#) and [step 2](#) in this section ([Clean the Upper and Lower Board](#)) for the lower board. Be sure to clean the solder joints adequately.



Solder joints

Pyramid Probes: Parametric PCB Cleaning

Baking and Reassembling the PCB

1. Bake the PCB in a 100°C oven for 1 hour.



CAUTION

- To prevent damage and/or contamination, set the PCB on a smooth, clean, stainless surface.
- The PCB will be hot when removed from the oven.



2. Carefully remove the PCB from the oven and set it on a flat, clean stainless steel surface. Allow it to cool to room temperature.
3. Re-install the PCB cover by reversing the steps described under [Remove the Core and PCB Cover](#) on page 1, including replacing the core in the PCB, and retest.

Notice of Normal Use

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Information in this document is subject to change without notice. The user has the responsibility to read and follow carefully all safety and use instructions. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Cascade Microtech, Inc. expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN.

The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user assumes all liability for misuse or alteration of the product, or for use in any manner not described in the Cascade Microtech, Inc. documentation.

Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

© Copyright 2015 Cascade Microtech, Inc. All rights reserved. Cascade Microtech is a registered trademark of Cascade Microtech, Inc. All other trademarks are the property of their respective owners.

Data subject to change without notice.

Cascade Microtech, Inc.
Corporate Headquarters
toll free: +1-800-550-3279
phone: +1-503-601-1000
email: cmi_sales@cmicro.com

Germany
phone: +49-89-9090195-0
email: cmg_sales@cmicro.com

Japan
phone: +81-3-5615-5150
email: cmj_sales@cmicro.com

China
phone: +86-21-3330-3188
email: cmc_sales@cmicro.com

Singapore
phone: +65-6873-7482
email: cms_sales@cmicro.com

Taiwan
phone: +886-3-5722810
email: cmt_sales@cmicro.com

